

UPPER RACK ASSEMBLY

SDWD28X10230

UPPER RACK ASSEMBLY INCLUDES

- Rack and roller assembly
- Upper spray tower and cap


INSTALLATION INSTRUCTIONS

1. Make sure rotating cap is secure on the top of the tower.
2. Secure the new upper spray tower to the center section of the new rack. Snap into place. (See Fig. 1)
3. Remove the end caps on the slide rails that are connected to the side of the dishwasher and remove the old rack.
4. Line up and glide the new upper rack assembled rollers into the slides and reinstall the rail caps. Make sure the caps are secure to prevent the rack from dislodging during the loading of dishes.
5. Run the dishwasher to make sure the spray tower is properly connected.

NOTE

- This rack is designed to replace several different rack styles used by the dishwasher manufacturer. Due to this, there may be some cosmetic variations in the rack configuration and mounting rollers.

FIG. 1



SUPPLYING DEMAND[®]

supplyingdemand.com



@therepairbrand | supplyingdemand