



INSTALLATION INSTRUCTIONS AND SAFETY PRECAUTIONS

FOR YOUR SAFETY, READ INSTRUCTIONS COMPLETELY AND CAREFULLY.

WARNING - POTENTIAL FIRE AND SHOCK HAZARD

IF YOU ARE NOT FAMILIAR WITH ELECTRICAL INSTALLATION, SEEK A QUALIFIED SERVICE PROFESSIONAL.



CONTENTS:

- APPLIANCE POWER CORD
- STRAIN RELIEF COLLAR AND SCREWS

SAFETY PRECAUTIONS

- SUPPLYING DEMAND ASSUMES NO RESPONSIBILITIES FOR INSTALLATION OF APPLIANCE CORD.
- DO NOT USE AN EXTENSION CORD.
- DO NOT USE IF CORD IS DAMAGED, CUT, WORN, OR FRAYED.
- DO NOT EXCEED ELECTRICAL RATINGS.
- IF YOUR APPLIANCE HAS A MANUAL TIMER AND IS NOT IN THE OFF POSITION, ENSURE THE APPLIANCE IS IN AN OFF STATE BEFORE INTRODUCING POWER.
- OBSERVE ALL GOVERNING CODES AND ORDINANCES.
- PROPER INSTALLATION IS THE RESPONSIBILITY OF THE INSTALLER.

BEFORE MAKING THE ELECTRICAL CONNECTION, TURN OFF THE CIRCUIT BREAKER(S) OR REMOVE THE APPLIANCE'S CIRCUIT FUSE(S) AT THE ELECTRICAL BOX. BE SURE THE POWER CORD IS UNPLUGGED FROM THE WALL.

NEVER LEAVE THE ACCESS COVER OFF THE TERMINAL BLOCK.

- PRODUCT FAILURE DUE TO IMPROPER INSTALLATION IS NOT COVERED UNDER THE WARRANTY.
- IMPROPER INSTALLATION OR WIRING ERRORS CAN CAUSE DAMAGE TO THE APPLIANCE, RESULT IN FIRE, OR CAUSE FATAL SHOCK.
- ALWAYS INSTALL STRAIN RELIEF.
- AFTER CORD IS PROPERLY INSTALLED, IT'S A BEST PRACTICE TO CHECK CONTINUITY OF GROUNDING CONNECTION BETWEEN THE METAL FRAME OF THE APPLIANCE AND THE CENTER PIN ON THE CORD WITH A MULTI-METER TO ENSURE THE APPLIANCE IS PROPERLY GROUNDED.



INSTALLATION INSTRUCTIONS

- 1. ENSURE YOUR CORD MATCHES THE APPLIANCE'S SPECIFICATIONS AND MEETS ALL APPLICABLE BUILDING AND/OR ELECTRICAL STANDARDS AND CODES.**
- 2. LOCATE TERMINAL BLOCK ACCESS COVER AND POWER CORD ENTRY KNOCKOUT ON APPLIANCE, IF EQUIPPED.**
- 3. INSTALL STRAIN RELIEF, IF INCLUDED, BY INSERTING EARS INTO KNOCKOUT HOLE AND USING SCREWS TO CONNECT TOP AND BOTTOM.**
- 4. INSERT POWER CORD LEADS THROUGH STRAIN RELIEF OPENING.**
- 5. SECURELY ATTACH POWER CORD TO TERMINAL BLOCK. ENSURE THE CABLE IS PROPERLY AND SECURELY ATTACHED. LOOSE CONNECTIONS CAN RESULT IN SHORT, FIRE, OR ELECTRICAL SHOCK.**
- 6. PUSH A FEW INCHES OF CORD THROUGH STRAIN RELIEF AND TIGHTEN.**
- 7. REINSTALL TERMINAL BLOCK COVER.**